

ProFicient

Branson X-Port Quick Start

Thank you for your interest in Branson X-Port. The following steps will guide you through the software installation process so that you can examine the software. For more information, please refer to the *Branson X-Port Module User's Guide* included with the CD.

1. Insert the Branson X-Port CD into the computer's CD-ROM drive. The **Branson X-Port** page opens.
2. In the **InfinityQS Software** page, click the latest Branson X-Port **Build** link, and run the Branson X-Port installer, following the screen instructions to install Branson X-Port.




3. When finished installing, start Branson X-Port by double clicking the **Branson X-Port** link on the desktop. Branson X-Port opens, prompting you for registration information.

4. In the **Registration Information** dialog box, type your user name and company name, and then click **OK**. The **Registration** dialog box opens.

5. In the **Registration** dialog box, click the **2. Register Purchased Copy** radio button, and then click **OK**. The **Registration Number** dialog box opens.

BRANSON X-PORT QUICK START

6. In the **Registration Number** dialog box, type your registration number (available on the Branson X-Port CD jacket), and then click **OK**. The **License Number** dialog box opens.



7. In the **License Number** dialog box, click the www.infinityqs.com/license.html button. The **User Information** page opens.

Note: If you do not have an internet connection, please contact InfinityQS technical support at (877) 772-7978 or (703) 961-0200.

8. Follow the instructions to complete your registration process.


9. When finished registering, configure the equipment settings in the **Equipment Settings** dialog box.

a. In the **Name** field, type the name that you are assigning to the welder.

b. In the **Communication Source** field, click the pull-down list and then click *Ethernet TCP/IP* or *RS-232*. For more information, please see the *Branson X-Port Module User's Guide*.

c. In the **IP Address** field, type the IP address assigned to the welder. For more information, please see the *Branson X-Port Module User's Guide*.

d. In the **IP Port** field, type 4000.



10. When finished, click **OK**. The **Equipment Settings** dialog box closes.



BRANSON X-PORT QUICK START

11. In Branson X-Port, set the **Part** and **Characteristics** for the desired welders, and then click the **Start** button.
12. Begin collecting data. Branson X-Port displays the characteristic distribution.

